



## LADA

### 1200,1300,1500,1600

←⊕ ALL TYPES 48 Lucas 01-73->01-87 248002

### 2101, 2102, 2103, 2104, 2105, 2106

→⊕ ALL TYPES 19 Fiat 119007

→⊕ ALL TYPES 19 Bdx 119009

→⊕ ALL TYPES 19 Fiat Basic parts 119072

←⊕ ALL TYPES 48 248023 248966 P484802 2 48

→⊕ ALL TYPES 19 Bdx 319024

→⊕ ALL TYPES 19 319056

→⊕ ALL TYPES 20.6 320017

→⊕ ALL TYPES 19 419002

→⊕ ALL TYPES 19 Bdx 519002

→⊕ ALL TYPES 613002

### NATACHA

→⊕ ALL TYPES 20.6 320017

### NIVA (2121)

→⊕ ALL TYPES 19 Fiat 119007

→⊕ ALL TYPES 19 Fiat Basic parts 119072

←⊕ ALL TYPES 30 230003

→⊕ ALL TYPES 19 Bdx 319024

→⊕ ALL TYPES 19 319056

→⊕ ALL TYPES 20.6 320017

→⊕ ALL TYPES 19 419002

→⊕ ALL TYPES 19 Bdx 519002

→⊕ ALL TYPES 613002

### NOVA

←⊕ Sedan 48 Lucas 01-81-> 248002

→⊕ ALL TYPES 20.6 320017

### RIVA

←⊕ ALL TYPES 48 Lucas 01-83-> 248002

### SAMARA (2108,2109), FORMA (21099)

→⊕ ALL TYPES 20.6 120022

←⊕ ALL TYPES 48 248023 248966 P484802 2 48

←⊕ ALL TYPES 48 01-86-> 248018 248911 P485302 1 53.6

→⊕ ALL TYPES 20.6 320017